

Hold North on the 360 Radial Hold North on the 010 Radial

Hold Northeast on the 020 Radial Hold Northeast on the 030 Radial

Hold Northeast on the 040 Radial Hold Northeast on the 050 Radial

Hold Northeast on the 060 Radial Hold Northeast on the 070 Radial

Hold East on the 080 Radial Hold East on the 090 Radial

Hold East on the 100 Radial Hold Southeast on the 110 Radial

Hold Southeast on the 120 Radial Hold Southeast on the 130 Radial

Hold Southeast on the 140 Radial Hold Southeast on the 150 Radial

Hold Southeast on the 160 Radial Hold South on the 170 Radial

Hold South on the 180 Radial Hold South on the 190 Radial

Hold Southwest on the 200 Radial	Hold Southwest on the 210 Radial
Hold Southwest on the 220 Radial	Hold Southwest on the 230 Radial
Hold Southwest on the 240 Radial	Hold Southwest on the 250 Radial
Hold West on the 260 Radial	Hold West on the 270 Radial

Hold West on the 280 Radial Hold Northwest on the 290 Radial

Hold Northwest on the 300 Radial	Hold Northwest on the 310 Radial
Hold Northwest on the 320 Radial	Hold Northwest on the 330 Radial
Hold Northwest on the 340 Radial	Hold Northwest on the 350 Radial
Hold North on the 360 Radial Left Turns	Hold North on the 010 Radial Left Turns
Hold Northeast on the 020 Radial Left Turns	Hold Northeast on the 030 Radial Left Turns

Hold Northeast on the 040 Radial **Left Turns**

Hold Northeast on the 050 Radial **Left Turns**

Hold Northeast on the 060 Radial **Left Turns**

Hold Northeast on the 070 Radial Left Turns

Hold East on the 080 Radial **Left Turns**

Hold East on the 090 Radial **Left Turns**

Left Turns

Hold East on the 100 Radial Hold Southeast on the 110 Radial **Left Turns**

Hold Southeast on the 120 Radial Hold Southeast on the 130 Radial **Left Turns**

Left Turns

Hold Southeast on the 140 Radial **Left Turns**

Hold Southeast on the 150 Radial **Left Turns**

Hold Southeast on the 160 Radial Left Turns

Hold South on the 170 Radial Left Turns

Hold South on the 180 Radial **Left Turns**

Hold South on the 190 Radial **Left Turns**

Hold Southwest on the 200 Radial **Left Turns**

Hold Southwest on the 210 Radial Left Turns

Hold Southwest on the 220 Radial Hold Southwest on the 230 Radial **Left Turns**

Left Turns

Hold Southwest on the 240 Radial **Left Turns**

Hold Southwest on the 250 Radial **Left Turns**

Hold West on the 260 Radial **Left Turns**

Hold West on the 270 Radial **Left Turns**

Hold West on the 280 Radial **Left Turns**

Hold Northwest on the 290 Radial **Left Turns**

Hold Northwest on the 300 Radial Hold Northwest on the 310 Radial **Left Turns**

Left Turns

Left Turns

Hold Northwest on the 320 Radial Hold Northwest on the 330 Radial Left Turns

Hold Northwest on the 340 Radial Hold Northwest on the 350 Radial **Left Turns**

Left Turns